

Chain Maille Bangle Bracelet

Supplies:

20 to 26 15mm Orings

40 to 52 16 gauge 1/4" orings

2 pairs flat nose pliers

1 pair needle nose pliers



1. Close 2 jump rings and then use needle nose pliers to pull 1 oring through.



2. Fold oring in half and insert one 1/4" jump ring. Close it.



3. Insert a second jump ring through the oring just as in step 2.



4. Use needle nose pliers to pull another oring through the 2 1/4" jump rings that were just inserted.



5. Repeat step 2, 3 and 4 until desired size. Finish piece by opening your starting jump rings one at a time and attaching them to the final oring.