

Brick Layer Weave

Supplies:

48 to 60 Orings 15mm Black

48 to 60 Orings 10mm Olive

24 to 30 Orings 10mm Dark Teal

24 to 30 Jump Rings 16g 5/16" Yellow

Tools: 1 pair Flat Nose Pliers

1 pair curved needle nose pliers

1 pair long needle nose pliers



1. Use long needle nose pliers to pull 3 10mm orings onto 2 15mm Orings. Place a 10mm oring onto the pliers then grab the 2 15mm orings with the pliers to pull the 10mm oring over the 2 15mm ones. Repeat this with all 3 10mm orings.



2. Open 1 jump ring and pass through the side (the 3 10mm Orings), the end of a group (the 2 black 15mm orings), the side of a group and then the end of a group. Close jump ring. (hold one side of jump ring with curved pliers and close other side of the jump ring with the flat nose pliers)



3. Open another jump ring and pass it through the side of the group on the end and the top of the group on the side.



4. Add another group to this jump ring attaching it on it's end. Close the jump ring.



5. Repeat steps 3 and 4 on the other side.



6. Open 1 jump ring and pass through the side (the 3 10mm Orings), the end of a group (the 2 black 15mm orings), the side of a group and then add an end group. Close jump ring. (hold one side of jump ring with curved pliers and close other side of the jump ring with the flat nose pliers)



7. Continue pattern of adding 2 groups on the sides and one group in the middle until you reach slightly larger than wrist length



8. Connect pattern using 3 final jump rings. Connect the center first and then the 2 sides.

